14 Mounting Instructions



Instructions for permanently mounting the I4 SCRUSHER®

The SCRUSHER $^{\circledR}$ can easily be mounted on any wood deck, flat surface, or any board of your making.

(Bolts not included)

For portable use

To enable you to pick up and use the SCRUSHER® anywhere, the following base is available: Black Lacquered Steel (19" X 15")

(Model I-4S) Steel Base (8lbs.) (*Base sold separately)



Instructions for permanently mounting the SCRUSHER®

1. Remove protective booties on each leg



2. Set drill holes




3. Drill down through holes



4. Complete





Instructions for mounting I4 to Base



1. Remove protective booties on each leg to expose the pre-drilled holes (4)



2. Place SCRUSHER on the base and line up drill holes



3. Drop bolts through holes (4) and drill down through holes



4. Securely fasten nuts (4) on the other side



5. Complete



